
10
18
LOCAL STORAGE
26
APPLICATIONS DEFINITIONS
28
MEMORY
16
VIRTUAL MACHINE SOFTWARE
24
DEVICE OPERATING SYSTEM
20
WIRELESS INTERFACE HARDWARE
14
PROCESSOR
12
22

FIG. 1


24
SCREEN GENERATION ENGINE 67
OBJECT CLASSES 69
EVENT HANDLER 65
XML PARSER 61

FIG. 2


10
NETWORK GATEWAY 40
WIRELESS NETWORK 1 36
TRANSACTION SERVER 44
30
46
NETWORK GATEWAY 42
34
WIRELESS NETWORK 2 38
32

FIG. 3


XML APPLICATION DEFINITION 28
USER INTERFACE DEFINITION SECTION 48
NETWORK TRANSACTION DEFINITION SECTION 50
DEVICE LOCAL DATA DEFINITION SECTION 52

FIG. 4

```
<ARML>
     <SCREEN>
          <MENU>
               <MENUITEM>
                    <EVENTS>
                         <ACTION>...</ACTION>
                    <EVENTS>
               </MENUITEM>
          </MENU>
          <BUTTONS>
                    (button definitions)
           </BUTTONS>
          <TEXTITEMS>
                    (textitems definitions)
          </TEXTITEMS>
          <EDITBOXES>
                    (editboxes definitions)
          </EDITBOXES>
          <CHOICEITEMS>
                    (choiceitems definitions)
          </CHOICEITEMS>
          <MESSAGEBOXES>
                    (messageboxes definitions)
          </MESSAGEBOXES>
          <IMAGES>
                    (images definitions)
          </IMAGES>
          <LISTBOXES>
                    (listboxes definitions)
          </LISTBOXES>
          <CHECKBOXES>
                    (checkboxes definitions)
          </CHECKBOXES>
     </SCREEN>
</ARML>
```

FIG. 5


DEVICE 10
DEVICE 30
USER INTERFACE DEVICE 10 48
NETWORK TRANSACTIONS 50
DATA 52
USER INTERFACE DEVICE 30 54
NETWORK TRANSACTIONS 50
DATA 52
58
USER INTERFACE DEVICE 10 48
USER INTERFACE DEVICE 30 54
...
USER INTERFACE DEVICE N 56
NETWORK TRANSACTIONS 50
DATA 52

FIG. 6


44
LOCAL STORAGE
46
MASTER DEFINITIONS
58
MEMORY
64
TRANSACTION SERVER SOFTWARE
68
QUEUES
71
DEVICE OPERATING SYSTEM
62
NETWORK INTERFACE HARDWARE
66
PROCESSOR
60
APPLICATION SERVER
70
DATA NETWORK
63
VIRTUAL MACHINE
24

FIG. 7

```
private void _Send(int applicationID, int mobileID, String
                        message,
                    int messageType)
                        {
                        try
                         {
          // Insert message into the application queue
                            ...

   // Lookup delivery type and push details for application
 String sql = "SELECT LNGDELIVERYTYPE, TXTDELIVERYDETAILS, " +
     "FROM TBLAPPLICATIONS WHERE LNGID = " + applicationID;

          IDataReader reader = ExecuteQuery(sql);
                    if (!reader.Read())
                  throw new Exception("...");

      int deliveryType = (int)reader["LNGDELIVERYTYPE"];
                  String deliveryDetails =
          (String)reader["TXTDELIVERYDETAILS"];

               if (deliveryType != POLL_HTTP)
                        {
        // This application uses a push delivery type
   IAIRIXEnterpriseWakeup entWakeup = (IAIRIXEnterpriseWakeup)
            Marshal.BindToMoniker("queue:/new:" +

"Nextair.AIRIX.Server.Enterprise.Router.AIRIXEnterpriseWakeup");
          entWakeup.Wakeup(applicationID, deliveryType,
                    deliveryDetails);
                        }
                    }
```

FIG. 8

```
public void Retry()
{
// Select all push-enabled applications that have expired
queued messages
string sql = "SELECT DISTINCT LNGAPPLICATIONID,
LNGDELIVERYTYPE, " +
"TXTDELIVERYDETAILS " +
"FROM TBLAPPLICATIONS A, TBLAPPLICATIONQUEUE Q " +
"WHERE A.LNGDELIVERYTYPE <> " + POLL_HTTP +
"AND Q.LNGAPPLICATIONID = A.LNGID " +
"Q.DTMQUEUED < " + expiryDate;

// Get a disconnected list of apps to retry
NextairDisconnectedDataProvider dp = new
NextairDisconnectedDataProvider();
DataSet ds = dp.ExecuteQuery(sql);
foreach (DataRow row in ds.Tables[0].Rows)
{
int appID = (int)row["LNGID"];
int deliveryType = (int)row["LNGDELIVERYTYPE"];
string deliveryDetails = (string)row["TXTDELIVERYDETAILS"];

// Call the Wakeup method for this application asyncronously
IAIRIXEnterpriseWakeup entWakeup = (IAIRIXEnterpriseWakeup)
Marshal.BindToMoniker("queue:/new:" +

"Nextair.AIRIX.Server.Enterprise.Router.AIRIXEnterpriseWakeup");
entWakeup.Wakeup(appID, deliveryType, deliveryDetails);
}
}
```

FIG. 9

```
public class AIRIXLockManager
{
private static Object lockSync = new Object();
private static Hashtable locks = new Hashtable();

public static bool ObtainLock(int lockID)
{
// Make sure only one caller can attempt to obtain a lock at
once.
// We don't bother locking per application, since this method
is
// expected to execute extremely quickly.
lock (lockSync)
{
if (!locks.Contains(lockID))
{
// This is the first attempt to lock this lock ID
locks[lockID] = true;
return true;
}

if (locks[lockID])
return false; // this ID is already locked

// Can successfully obtain the lock for this lock ID
locks[lockID] = true;
return true;
}
}

public static void ReleaseLock(int lockID)
{
lock (lockSync)
{
locks[lockID] = false;
}
}
}
```

FIG. 10

```
[InterfaceQueuing]
public interface IAIRIXEnterpriseWakeup
{
void Wakeup(int appID, int deliveryType, String
deliveryDetails);
}

public class AIRIXEnterpriseWakeup :
NextairDatabase, IAIRIXEnterpriseWakeup
{
private bool _clustered = false;
private String _lockProvider = String.Empty;

public void OnConstruct(String constructString)
{
clustered = ...; // read config from config
if (clustered)
_lockProvider = ...; // read lock server location from
config
}

private bool _obtainLock(int appID)
{
if (_clustered)
return RemotingServer.ObtainLock(appID); // call remoting
server
else
return AIRIXLockManager.ObtainLock(appID); // obtain local
lock
}

private void _releaseLock(int appID)
{
if (_clustered)
RemotingServer.ReleaseLock(appID); // call remoting server
else
AIRIXLockManager.ReleaseLock(appID); // release local lock
}

public void Wakeup(int appID, int deliveryType,
String deliveryDetails)
{
if (_obtainLock(appID))
{
try
{
// Obtain a disconnected list of queued messages, ordered
// oldest -> newest.
DataSet messages = RetrieveQueuedMessages(appID);
```

FIG. 11A

```
// Loop through each queued message and attempt to push
                        it
    foreach (DataRow msg in messages.Tables[0].Rows)
                            {
          AIRIXEnterprisePushBase pushObj = null;
                            try
                             {
       pushObj = _createPushComponent(deliveryType);
                    if (pushObj ==  null)
     ... // unable to create push component for delivery
                        type

          // Synchronously push this message out
    int result = pushObj.Push(appID, (int)msg["LNGID"],
                (int)msg["LNGMESSAGETYPEID"],
         (String)msg["VARMOBILEID"], deliveryDetails);

          if (!AIRIXConstants.Succeeded(result))
         ... // throw exception so that pushing stops
                             }
                    catch (Exception x)
                             {
    ... // log this push msg error and break out of push
                        loop
                             }
                        finally
                             {
    NextairServicedComponent.DisposeComponent(pushObj);
                             }
                           }
                         }
                      finally
                           {
                  _releaseLock(appID);
                           }
                        }
                      }
                    }
```

FIG. 11B

```
public interface IAIRIXEnterprisePush
                    {
// Called by AIRIX to push an application-bound message out
 bool AIRIXReceiveData(int appID, string mobileID, string
                    data);

// Called by AIRIX when a mobile-bound message delivery fails
 bool AIRIXDeliveryError(int appID, string mobileID, string
                    data,
          int errorCode, string errorDescription);

// Called by AIRIX when a mobile-bound message is delivered
 bool AIRIXDeliveryNotify(int appID, string mobileID, string
                    data);
                    }
```

FIG. 12

```
public class AIRIXEnterprisePushBase : NextairDatabase
                                {
        protected int moveQueueToLog(int queueID)
                                {
 // Move the specified message from the Application Queue
   // to the Application Log, and return an appropriate
                  // AIRIXConstants result.
                                ...
                                }

public int Push(int appID, int queueID, String message,
int messageType, String mobileID, String deliveryDetails)
                                {
          IAIRIXEnterprisePush pushClient = null;
                                try
                                 {
  // Move the message from the queue to the log first. It
                                will be
             // rolled back if the PUSH fails.
            int result = moveQueueToLog(queueID);
           if (!AIRIXConstants.Succeeded(result))
         ... // abort the transaction and return error

      // Create an instance of IAIRIXEnterprisePush.
  // This logic is left up the the child class, since this
                                process
 // can differ depending on the type of communication used.
   pushClient = createPushClient(appID, deliveryDetails);

                  if (pushClient == null)
     throw new Exception("Invalid interface reference.");

   // Push the message out using the retrieved interface
                    bool success = false;
                     switch (messageType)
                                 {
              case MessageTypes.APPLICATION_DATA:
          success = pushClient.AIRIXReceiveData(appID,
                                mobileID, message);
                                break;

            case MessageTypes.DELIVERY_CONFIRMATION:
         success = pushClient.AIRIXDeliveryNotify(appID,
                                mobileID, message);
                                break;

           case MessageTypes.FAILURE_NOTIFICATION:
             int errorCode = getErrorCode(message);
             int errorMsg  = getErrorMsg(message);
         success = pushClient.AIRIXDeliveryError(appID,
            mobileID, message, errorCode, errorMsg);
                                break;
```

FIG. 13A

```
                default:
        throw new Exception("Invalid message type: " +
                    messageType);
                    }
                if (!success)
                    {
            // Log error or warning and exit...
                    _SetAbort();
        return AIRIXConstants.ENTERPRISE_PUSH_FAILED;
                    }

            return AIRIXConstants.SUCCESS;
                    }
                catch (Exception x)
                    {
                // Log error...
                    _SetAbort();
        return AIRIXConstants.ENTERPRISE_PUSH_UNKNOWN_ERROR;
                    }
                finally
                    {
              if (pushClient != null)
            disposePushClient(pushClient);
                    _SetComplete();
                    }
                    }

// Abstract method that children will implement to do the work
        // of pushing the message to an application.
 protected abstract IAIRIXEnterprisePush createPushClient(int
                    appID,
                String deliveryDetails);

// Overridable method that children can implement to provide
  // component specific cleanup of the IAIRIXEnterprisePush
                    client
        // created via the createPushClient method.
    protected void disposePushClient(IAIRIXEnterprisePush
                    pushClient)
                    {
          // Base class implementation does nothing.
 // Children can optionally override this to perform explicit
     // cleaning up of the previously created push client
                    component.
                    }
                    }
```

FIG. 13B

```
[
uuid(EF2795BE-3874-4ACF-A087-8113FB791211),
version(1.0),
helpstring("IAIRIXEnterprisePush Library")
]
library IAIRIXEnterprisePush
{
importlib("STDOLE2.TLB");

[
uuid(E7C20DA3-6820-4D3D-8E5C-A8BE61BFDFFE),
version(1.0),
dual,
oleautomation
]
interface IAIRIXEnterprisePush: IDispatch
{
[id(0x00000001)]
HRESULT _stdcall AIRIXReceiveData([in] long appID,
[in] BSTR mobileID, [in] BSTR data,
[out, retval] VARIANT_BOOL * Result);

[id(0x00000002)]
HRESULT _stdcall AIRIXDeliveryError([in] long appID,
[in] BSTR mobileID, [in] BSTR data, [in] long errorCode,
[in] BSTR errorDescription,
[out, retval] VARIANT_BOOL * Result);

[id(0x00000003)]
HRESULT _stdcall AIRIXDeliveryNotify([in] long appID,
[in] BSTR mobileID, [in] BSTR data,
[out, retval] VARIANT_BOOL * Result);
};
};
```

FIG. 14

```
protected IAIRIXEnterprisePush createPushClient(int appID,
                    String deliveryDetails)
                                {
      // Get type/interface information from COM object
    Type type = Type.GetTypeFromProgID(deliveryDetails);
                        if (type == null)
     throw new Exception("Unable to create COM object: " +
                                    deliveryDetails);

          // Create an instance of the COM object
     Object instance = Activator.CreateInstance(type);
          if (!(instance is IAIRIXEnterprisePush))
   throw new Exception("COM object does not implement the "
                                +
                          "IAIRIXEnterprisePush interface.");

          return (IAIRIXEnterprisePush)instance;
                                }
```

FIG. 15

```
// Called by the ATS to deliver application-bound messages
bool AIRIXReceiveData(int appID, String mobileID, String data);

// Called by the ATS when a mobile-bound message delivery fails
bool AIRIXDeliveryError(int appID, String mobileID, String data,
                int errorCode, String errorDescription);

// Called by the ATS when a mobile-bound message is
// successfully delivered.
bool AIRIXDeliveryNotify(int appID, String mobileID, String
data);
```

FIG. 16

```
// Import the WSDL definition into a CodeDom namespace
        ServiceDescriptionImporter imp = new
            ServiceDescriptionImporter();
    DiscoveryProtocol dcp = new DiscoveryProtocol();
            dcp.DiscoverAny(wsdlLocation);
                dcp.ResolveAll();
      foreach (object o in dcp.Documents.Values)
                            {
                if (o is ServiceDescription)
imp.AddServiceDescription((ServiceDescription)o, null, null);
                if (o is XmlSchema)
                imp.Schemas.Add((XmlSchema)o);
                            }
          CodeNamespace ns = new CodeNamespace(
        "Nextair.AIRIX.Server.Enterprise.Push.WSDL");
                imp.ProtocolName = "Soap";
                  imp.Import(ns, null);

// Verify that all classes in the namespace have the proper
                        signature
        bool m1 = false, m2 = false, m3 = false;
      foreach (CodeTypeDeclaration t in ns.Types)
                            {
          if (t.IsClass && t.Name == typeName)
                            {
          foreach (CodeTypeMember m in t.Members)
                            {
        if (m.Name == "AIRIXReceiveData") m1 = true;
      else if (m.Name == "AIRIXDeliveryError") m2 = true;
     else if (m.Name == "AIRIXDeliveryNotify") m3 = true;
                            }
    t.BaseTypes.Add("Nextair.AIRIX.Server.Enterprise." +
                        "Push.IAIRIXEnterprisePush");
                            break;
                            }
                            }
                if (!(m1 && m2 && m3))
  throw new Exception("Incomplete interface definition.");
```

FIG. 17A

```
// Generate source code from the imported web service
CSharpCodeProvider provider = new CsharpCodeProvider();
ICodeGenerator gen = provider.CreateGenerator();
StringBuilder sb = new StringBuilder();
StringWriter sw = new StringWriter(sb);
gen.GenerateCodeFromNamespace(ns, sw, null);
string sourceCode = sb.ToString();
sb.Close();

// Compile the proxy assembly
CompilerParameters cp = new CompilerParameters();
cp.GenerateExecutable = false;
cp.GenerateInMemory = false;
cp.IncludeDebugInformation = false;
cp.ReferencedAssemblies.Add("System.dll");
cp.ReferencedAssemblies.Add("System.Xml.dll");
cp.ReferencedAssemblies.Add("System.Web.Services.dll");
cp.ReferencedAssemblies.Add("System.Data.dll");
cp.ReferencedAssemblies.Add(
typeof(IAIRIXEnterprisePush).Assembly.Location);
cp.OutputAssembly = proxyDir + applicationID.ToString() + ".dll";
ICodeCompiler compiler = cscp.CreateCompiler();
CompilerResults results;
results = compiler.CompileAssemblyFromSource(cp, sourceCode);
if (results.Errors.Count > 0)
throw new Exception("Build failed.");

// Cache handle to compiled assembly and add the soap interface
proxy
// type to the static list of cached proxies.
Assembly asm = results.CompiledAssembly;
Type proxyType = asm.GetType(
"Nextair.AIRIX.Server.Enterprise.WSDL." + typeName, true,
true);
cachedProxies[wsdlLocation] = proxyType;
```

FIG. 17B

```
protected IAIRIXEnterprisePush createPushClient(
          int appID, String deliveryDetails)
                    {
// Pull service location and name out of delivery details xml
          XmlDocument xml = new XmlDocument();
             xml.LoadXml(deliveryDetails);
                  string serviceUrl  =
   xml.DocumentElement.Attributes["Url"].Value;
                  string serviceName =
   xml.DocumentElement.Attributes["Name"].Value;

  // If the proxy for this service url is not yet cached,
                // build and cache it now.
        if (!cachedProxies.Contains(serviceUrl))
         _buildSoapProxy(serviceUrl, serviceName);

// Create an instance of the soap proxy for this web service
       Type type = (Type)cachedProxies[serviceUrl];
            IAIRIXEnterprisePush pushClient =
    (IAIRIXEnterprisePush)Activator.CreateInstance(type);
                  if (push == null)
  throw new Exception("Unable to create proxy instance.");

                  return (pushClient);
                  }
```

FIG. 18

```
public IAIRIXEnterprisePush createPushClient(int appID,
                    String deliveryDetails)
                                {
                // Retrieve delivery information
              XmlDocument xml = new XmlDocument();
                  xml.LoadXml(deliveryDetails);
                       string serviceName =
        xml.DocumentElement.Attributes["Name"].Value;
                int servicePort = Int32.Parse(
           xml.DocumentElement.Attributes["Port"].Value);
                     string serviceLocation =
          xml.DocumentElement.Attributes["Location"].Value;

       // Return a remote instance of IAIRIXEnterprisePush
        return (IAIRIXEnterprisePush)Activator.GetObject(
                        typeof(IAIRIXEnterprisePush),
       "tcp://" + serviceLocation + ":" + servicePort + "/" +
                                serviceName);
                                  }
```

FIG. 19

```
private void RetryTimer(object sender, EventArgs e)
                    {
          AIRIXEnterpriseRouter router = null;
                         try
                          {
            router = new AIRIXEnterpriseRouter();
                       router.Retry();
                          }
                  catch (Exception x)
                          {
                            ...
                          }
                       finally
                          {
      NextairServicedComponent.DisposeComponent(router);
                          }
                        }
```

FIG. 20

```
// Register a tcp channel for listening for remoting requests
  TcpChannel channel = new TcpChannel(configuredPortNumber);
          ChannelServices.RegisterChannel(channel);

  // Expose the AIRIXRemotingLockManager as a singleton type
        lockManager = new AIRIXRemotingLockManager();
    RemotingServices.Marshal(lockManager, "LockManager");
```

FIG. 21